

Reagent recovery from dairy industry wastewater through membrane processes

Rubén Rodríguez-Alegre, LEITAT Technological Center / Universitat Politècnica de Catalunya, Spain



INDEX

- Introduction
- Methodology
- Results
- Conclusions




RESEARCH FRAMEWORK

bio-mimetic and phyto-techNologies Designed for
low-cost purificAtion and recycling of water
(INDIA-H₂O)



RESEARCH FRAMEWORK


- India is ranked 1st in milk production contributing 26% of global milk production.
- Cleaning-in-place (CIP) requires large quantities of water in the dairy industry (nearly 75% of the total water required)
- Three stage process: basic cleaning, acid cleaning and detergent




SUSTAINABLE DEVELOPMENT GOALS



METHODOLOGY: EXPERIMENTAL SET-UP




METHODOLOGY: EXPERIMENTAL SET-UP



RESULTS: FORWARD OSMOSIS

$$SEC \left(\frac{Kwh}{m^3} \right) = \frac{\Delta P \cdot Q_{feed}}{Q_p}$$

Experimental conditions	C_{draw}^0 [mol/m ³]	C_{draw}^f [mol/m ³]	C_{feed}^0 [mol/m ³]	Q_p [m ³ /h]	ΔP [Pa]	SEC [kWh/m ³]
0.005M NaNO ₃	50	41	18	0.00098	$3.67 \cdot 10^3$	0.0324
0.125M NaNO ₃	125	100	18	0.00274	$3.67 \cdot 10^3$	0.0108
0.25M NaNO ₃	250	180	18	0.00616	$3.67 \cdot 10^3$	0.0046
0.50M NaNO ₃	500	370	18	0.01540	$3.67 \cdot 10^3$	0.0018



RESULTS: REVERSE OSMOSIS


$$SEC \left(\frac{Kwh}{m^3} \right) = \frac{\Delta P \cdot Q_{feed}}{Q_p}$$

Experimental conditions	C^0_{draw} [mol/m ³]	C^f_{draw} [mol/m ³]	C_{perm} [mol/m ³]	Q_p [l/h]	ΔP [bar]	SEC [kWh/m ³]
0.125M NaNO ₃	100	121	12.7	5.2	10.4	45.3
0.25M NaNO ₃	180	234	22.5	5.42	14.2	58.5
0.50M NaNO ₃	370	606	8.19	5.1	23.6	102.5

RESULTS: BIPOLAR MEMBRANE ELECTRODIALYSIS

$$CEE \left(\frac{kWh}{m^3} \right) = \frac{N \cdot I \cdot V}{Q_p}$$

Experimental conditions	% conc. HNO ₃	% conc. NaOH	N	Voltage [V]	Intensity [A]	Q _p (m ³ /h)	SEC [kWh/m ³]
0.05M HNO ₃ /NaOH	61.38	23.03	30	9.02	0.09	3 10 ⁻⁵	3.59
0.1M HNO ₃ /NaOH	182.82	77.83	30	9.02	0.09	3 10 ⁻⁵	16.48
0.2M HNO ₃ /NaOH	6.77	-55.33	30	9.02	0.12	3 10 ⁻⁵	4.59



CONCLUSIONS

- According to Forward Osmosis and Reverse Osmosis results, SEC and permeate quality, the optimal concentration of draw solution is 0.125 M NaNO_3 .
- In Electrodialysis tests, the best performance was reported for an initial concentration of 0.05 M for both acid and base as draw solution.
- In Electrodialysis, The concentration of NaNO_3 was reduced by 75%.
- The work done so far, yields promising results in the concentration and extraction of cleaning reagents for reuse in dairy industry.



THANK YOU



This project has received funding from the European Union's Horizon 2020 research and innovation programme under grant agreement No 820906 and the Indian Department of Biotechnology.